





Gerätetyp	Bestellnr. des Geräteherstellers	Vermes - Typen - Nr.	VE	RIKADENKI
DB-1	4620/I	4620 01 9 02 N 01	1	
DB-2	4620/I 4620/II	4620 01 9 02 N 01 4620 02 9 01 N 01	1 1	
DB-3	4620/I 4620/II 4620/III	4620 01 9 02 N 01 4620 02 9 01 N 01 4620 03 9 03 N 01	1 1 1	
DB-4, KA-42, KB-48, KB-481	4620/I 4620/II 4620/III 4620/IV	4620 01 9 02 N 01 4620 02 9 01 N 01 4620 03 9 03 N 01 4620 04 9 05 N 01	1 1 1 1	
DB-5, KA-52, KB-58, KB-581	4620/I 4620/II 4620/III 4620/IV 4620/V	4620 01 9 02 N 01 4620 02 9 01 N 01 4620 03 9 03 N 01 4620 04 9 05 N 01 4620 05 9 06 N 01	1 1 1 1 1	
DB-6, KA-62, KB-68, KB-681	4620/I 4620/II 4620/III 4620/IV 4620/V 4620/VI	4620 01 9 02 N 01 4620 02 9 01 N 01 4620 03 9 03 N 01 4620 04 9 05 N 01 4620 05 9 06 N 01 4620 06 9 04 N 01	1 1 1 1 1 1	
Kasset		4621 11 9 02 N 01	5	
		4621 12 9 01 N 01	5	

Gerätetyp	Bestellnr. des Geräteherstellers	Vermes - Typen - Nr.	VE	RIKADENKI
T-20	4631-6/I	4631 01 9 02 N 01	1	 <p>Maßstab 1:2 Scale 1:2</p>
	4631-/II	4631 02 9 01 N 01	1	
B-106, B-1061	4633-6/I	4633 01 9 02 N 01	1	 <p>Maßstab 1:2 Scale 1:2</p>
B-206, B-2061	4633-6/I	4633 01 9 02 N 01	1	
	4633-6/II	4633 02 9 01 N 01	1	
B-306, B-3061	4633-6/I	4633 01 9 02 N 01	1	
	4633-6/II	4633 02 9 01 N 01	1	
	4633-6/III	4633 03 9 03 N 01	1	
B-406, B-4061	4633-6/I	4633 01 9 02 N 01	1	
	4633-6/II	4633 02 9 01 N 01	1	
	4633-6/III	4633 03 9 03 N 01	1	
	4633-6/IV	4633 04 9 05 N 01	1	
B-506, B-5061	4633-6/I	4633 01 9 02 N 01	1	
	4633-6/II	4633 02 9 01 N 01	1	
	4633-6/III	4633 03 9 03 N 01	1	
	4633-6/IV	4633 04 9 05 N 01	1	
	4633-6/V	4633 05 9 06 N 01	1	
B-606, B-6061	4633-6/I	4633 01 9 02 N 01	1	
	4633-6/II	4633 02 9 01 N 01	1	
	4633-6/III	4633 03 9 03 N 01	1	
	4633-6/IV	4633 04 9 05 N 01	1	
	4633-6/V	4633 05 9 06 N 01	1	
	4633-6/VI	4633 06 9 04 N 01	1	

Gerätetyp	Bestellnr. des Geräteherstellers	Vermes - Typen - Nr.	VE	RIKADENKI
B-18, B-181 B-108, B-1081	4639/I	4639 01 9 02 N 01	1	
B-28, B-281 B-208, B-2081	4639/I 4639/II	4639 01 9 02 N 01 4639 02 9 01 N 01	1 1	
B-38, B-381 B-308, B-3081	4639/I 4639/II 4639/III	4639 01 9 02 N 01 4639 02 9 01 N 01 4639 03 9 03 N 01	1 1 1	
B-408, B-4081	4639/I 4639/II 4639/III 4639/IV	4639 01 9 02 N 01 4639 02 9 01 N 01 4639 03 9 03 N 01 4639 04 9 05 N 01	1 1 1 1	
B-508, B-5081	4639/I 4639/II 4639/III 4639/IV 4639/V	4639 01 9 02 N 01 4639 02 9 01 N 01 4639 03 9 03 N 01 4639 04 9 05 N 01 4639 05 9 06 N 01	1 1 1 1 1	
B-608, B-6081	4639/I 4639/II 4639/III 4639/IV 4639/V 4639/VI	4639 01 9 02 N 01 4639 02 9 01 N 01 4639 03 9 03 N 01 4639 04 9 05 N 01 4639 05 9 06 N 01 4639 06 9 04 N 01	1 1 1 1 1 1	
B-107	4640	4640 00 9 02 N 01	1	 <p>Maßstab 1:2 Scale 1:2</p>  <p>Maßstab 1:2 Scale 1:2</p>

Gerätetyp	Bestellnr. des Geräteherstellers	Vermes - Typen - Nr.	VE	RIKADENKI
R-01 - R-03	4658/I	4658 01 9 02 N 01	1	<p>Technical drawing showing the heights of recording pens 01 through 10. The heights are: 01: 14.3, 02: 26.3, 03: 38.3, 04: 50.3, 05: 62.3, 06: 74.3, 07: 86.3, 08: 98.3, 09: 110.3, 10: 122.3. A detail drawing of the pen tip shows a length of 15 and a diameter of M10x0,7. The overall scale is 1:2.</p>
R-001+002	4658/II	4658 02 9 01 N 01	1	
R-11, R-21	4658/III	4658 03 9 03 N 01	1	
R-101, R-201	4658/IV	4658 04 9 05 N 01	1	
R-12, R-22,	4658/V	4658 05 9 06 N 01	1	
R-102, R-202	4658/VI	4658 06 9 04 N 01	1	
R-13, R-103	4658/VII	4658 07 9 09 N 01	1	
R-14, R-104	4658/VIII	4658 08 9 10 N 01	1	
R-15, R-105	4658/IX	4658 09 9 07 N 01	1	
R-16, R-106	4658/X	4658 10 9 11 N 01	1	
R-51 - R-5X				
R-301 - R-308				
Kasset TO2N1		4688 00 9 01 N 01	5	
XY-Schreiber		4688 00 9 02 N 01	5	
BW-133, RW-11,		4688 00 9 03 N 01	5	
RY-1MZ, RY-2M,		4688 00 9 04 N 01	5	
RY-10MZ, RY-11,		4688 00 9 05 N 01	5	
RY-11Z, RY-20M,		4688 00 9 06 N 01	5	
RY-21, RY-101				
RY-101Z, RY-102,				
RY-102Z,				
RY-201				